

Elite™ iOS Quick Start Guide for Zello




For the most up-to-date app settings and configurations, check zello.com/support.




1. Before plugging your Elite™ speaker-microphone (SM) into the iOS device, set the configuration to 2 by pressing the rear button for 4 seconds. The SM will then beep twice in quick succession.

2. The SM will beep and flash a red LED a number of times equal to the current configuration.

- **If the SM indicates configuration 2**, don't do anything. After 4 seconds, the SM will beep twice in quick succession indicating it is ready for use.
- **If the SM indicates some configuration other than 2**, press the rear button 2 times. The SM will then beep and flash the LED 2 times as confirmation. After 4 seconds, the SM will beep twice in quick succession indicating it is ready for use.



3. Plug the SM into the device. Launch Zello and tap the account icon in the top left corner and select **Settings**.



4. Select **Push-to-talk buttons** > **Headset Button** and select **PTT headset**.

Innovation... Quality... Passion

Designed, Assembled, Tested and Supported with Pride in the USA, at Stone Mountain we strive to provide our customers with innovative products of the highest quality, reliability and value. We welcome and appreciate your input - Feel free to contact us.

Stone Mountain, Ltd.
1597 Eagle Point Road
Huddleston, VA 24104

31Mar25

Customer Support: 540.297.6434

www.stonemountainltd.com